HD DEEP-V AIRLESS CART Model # 22-6700



PARTS LIST	
Qty	Name
1	HD Deep-V Cart Frame
2	Strap Sets
2	10" Airless Wheel
2	Quick-Release Pin
1	Mesh Carrying Bag

Holds up to 200 LBS

Assembly

- 1. Unfold cart and remove Quick-Release Pins from the axle by flipping the ring upwards and outwards.
- 2. Slide wheels onto frame and replace Quick-Release Pins in hole next to wheels and flip the lock ring over the end of axle to secure the pin.
- 3. Attach straps to cart by threading the end of each strap through loop on other end of strap and pull tight around tubing of cart. Place both long straps on one side of cart and short cam lock straps on opposite side.







FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

Rev. 9/17



HD DEEP-V AIRLESS CART Page 2

Use

- 1. Position the cart next to the center of the boat with the kickstand facing the direction the boat will be pulled.
- 2. Lift one end of the boat and pivot, setting it down on the rubber pads on the cart.
- 3. Loop each set of straps around boat making sure the non-marring buckle protection fabric is under the buckle before pulling tight.
- 4. Lift one end of the boat, kick the kickstand up and away you go!



Make it a Sand Cart by adding Balloon Wheels (Model #22-2219).

Care

Rinse cart after each use to clean off sand, salt and mud.

Caution

This cart is designed for hand towing only. It is not intended to be pulled behind a bicycle or motorized vehicle.

Visit www.Suspenz.com for additional transportation and storage solutions.



Small Universal Boat Stands





FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

OUR PLEDGE TO YOU

Suspenz® products are warrantied for life against defects in material or workmanship to the original owner. Product must be used for its intended purpose under normal conditions. Please visit www.Suspenz.com for complete warranty information.

SUSPENZ®, INC. 8725 ROSWELL ROAD #0-220 ATLANTA GA 30350



CUSTOMER SERVICE:770-518-0045 FAX: 770-518-8507 WEBSITE: WWW.SUSPENZ.COM