

AIRLESS END CART

Model # 22-8899

Model # 22-0099



Assembly

Tools Needed:

2 Adjustable Wrenches

1. Bolt wheels to frame.
2. Tighten outer nut until wheel stops turning, then unscrew the nut $\frac{1}{2}$ turn.

Use

1. Adjust height of the side tubes if needed so that the top tube rests on top of the boat with the cart angled forward as shown in picture. (Approximately the thickness/depth of your boat plus 4".)
2. With the cart leaning forward at about a 45 degree angle, slide either end of boat into the cart opening with the boat keel sitting in the bottom "V" padding.
3. The boat should slide in about $\frac{1}{4}$ - $\frac{1}{3}$ of the boat's length.
4. Pull bungee cord tight and connect it to a secure place in or around the cockpit.
5. Lift opposite end of the boat and away you go!

PARTS LIST	
Qty	Name
1	Adjustable Cart Frame
2	10" Airless Wheel

Holds up to 150 LBS

Care

Rinse cart after each use to clean off sand, salt and mud.

Caution

This cart is designed for hand towing only. It is not intended to be pulled behind a bicycle or motorized vehicle.



Scan* to see
Video Instructions
for Assembly & Use
or

Visit Suspenz.com
"Video & Manual" page
*QR code reader app required

Rev. 11/16

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

OUR PLEDGE TO YOU

Suspenz® products are warrantied for life against defects in material or workmanship to the original owner. Product must be used for its intended purpose under normal conditions. Please visit www.Suspenz.com for complete warranty information.

SUSPENZ®, INC.
8725 ROSWELL ROAD #0-220
ATLANTA GA 30350



CUSTOMER SERVICE: 770-518-0045
FAX: 770-518-8507
WEBSITE: WWW.SUSPENZ.COM