

## STAR Kayak Seat Installation



1. Peel apart the two hook-and-loop closure strips on the underside of the seat.



2. Slide the strip ends through both sets of webbing loops on the drop-stitch floor of the kayak.



3. Press the seat down to rejoin the hook-and-loop surfaces.



4. Clip the front and back seat adjustment straps (four total) to the D-rings mounted low on the inside of the tubes.



5. Adjust the tension on the straps for the desired seat-back position.

