

DUAL-CHAMBER PADDLE FLOAT INSTRUCTIONS



USING YOUR DUAL-CHAMBER PADDLE FLOAT

STEP 1

Insert paddle blade into partially inflated paddle float.

STEP 2

Inflate both sides of the dual-chamber paddle float.

STEP 3

Fasten the quick release buckles around the paddle shaft.



FOR EXPERIENCED PADDLERS ONLY

BEGINNERS SHOULD BE TAUGHT BY QUALIFIED INSTRUCTORS IN THE USE OF PADDLE FLOATS AND RESCUE

USING YOUR PADDLE FLOAT IN A SELF RESCUE

STEP 1

Flip the kayak right-side up and locate your paddle float.

**It is best to store your paddle float securely on the deck under the stern bungee cords for easy access.*

STEP 2

Stay connected to the kayak by clipping the paddle float to the boat. Insert one paddle blade into the paddle float and finish inflating. Inflate by turning the valve end counter-clockwise and blowing into the valve. Turn valve end clockwise to close.

STEP 3

Fasten the quick release buckles around the paddle shaft and insert the opposite paddle blade under the deck bungee near the cockpit. The paddle float should be floating on the surface of the water and the paddle should be at a 90° angle to the kayak.

STEP 4

Holding the kayak paddle shaft and cockpit edge, pull your body onto the kayak. With one foot on the paddle (above float) for leverage, place your other foot into the cockpit. Still holding the paddle for balance, slide into the seat.


STEP 5

Bring the paddle in front of you and use it for support while you bilge the water from your kayak. When finished, deflate the paddle float and slip it off of the paddle. Secure the paddle float back onto the deck and be on your way.

STEP 1



STEP 2



STEP 3



STEP 4



STEP 5



WARNING

Due to the fact that Seattle Sports does not have control over how this device is used, Seattle Sports disclaims any and all liability for damage or injury that might occur as a result of the improper use of this product.

WARRANTY

Seattle Sports products are guaranteed for materials and workmanship for one year. Normal wear and tear or damage from misuse, accident, or alterations are not covered. Use of this product in a professional setting is not covered. Seattle Sports assume no liability for incidental damages or injuries resulting from the use or misuse of this product. You may have additional warranties or limitations outlined in product packaging. Thank you for purchasing our products. Please contact us with any questions or concerns about our products. Seattle Sports Company, 3217 W. Smith St #1, Seattle WA 98199. Copyright 2

seattlesportsco.com